

Assembly Instruction For 21266

- 1. Turn the nipple into the coupler then secure by the hex nut.
- 2. Attach the cap on the nipple then secure by the loop.
- 3. Turn then nipple 1 into the coupler 1 then secure by the hex nut 1.
- 4. Attach the cap 1 on the nipple 1 then secure by the ball.
- 5.Attach the glass and metal washer on the socket then secure by the socket ring.

