



## Assembly Instruction For 21345

1. Insert the cap(B),tube(C) to the nipple(D), then secured by loop(A) to the nipple(D);
2. Secured the finial(E1) to the nipple(F); through the nipple(F) to cap(G) metal plate(H) and notch cap (I); final secured the finial(E) to the nipple(F)
3. Place the metal shade(O), glass shade(L) and metal washer(K) on the socket(P), then locked by the socket ring(J)

