

Assembly Instruction For21504

- 1. Put the tube1 on the coupler, then locked it till tighten.
- 2. Put the tube on the nipple, then locked it till tighten.
- 3. Place the shade frame on the socket, then secured by socket ring.
- 4. Place the glass shade and rubber washer on the shade frame, then secured by the finial.

